


**RhySearch Optical Coatings Lab:**  
***Laser Induced Damage Threshold (LIDT)***  
***Testing***


# Overview

- What is the LIDT of a component?
- What can influence the LIDT of a component?
- Different measurement strategies:
  - Measurement according to the ISO 21254 Standard
    - Single-Shot Test (1-on-1)
    - Multishot Test (S-on-1)
    - Certification
  - R-on-1 Ramp-Test
  - Raster Scan



# What is the LIDT of a component?

- Any permanent change in the surface or substrate properties of an optical element caused by laser radiation
  - The most common form of laser destruction is the physical damage to coated optical surfaces
  - Often discoloration and delamination also occur
  - Minor changes in the substrate properties due to laser radiation can already be considered laser damage in sensitive applications
- *ISO 21254: any visual change after laser radiation observed with a Nomarski Differential Interference Contrast (DIC) microscope at 10x enlargement is to be considered as damaged*



For further reading, please refer to:  
Detlev Ristau (Ed.), *Laser-Induced Damage in Optical materials*, CRC Press, 2015.

# What can influence the LIDT of a component?

## ■ Laser radiation

- Damage mechanism depends on the pulse duration:
  - ns-pulses: Defect induced (heating of defects)
  - fs-pulses: Electronically triggered damage (Electron tunneling, multi-photon absorption or a combination of the two, avalanche ionization, optical breakdown → *intrinsic damage*)
  - ps-pulses: transition between the two regimes: both due to intrinsic effects and defect induced
  - cw laser and ultra-short pulsed lasers: absorption
- **Lateral beam profile**: Laser mode has a strong influence on the peak intensity
- **Temporal beam profile**: Depending on the laser peak intensities can vary strongly
- **Wavelength**: UV radiation: colour centres or higher probability of multi-photon absorption; IR: absorption of OH-groups

→ The longer the pulse duration, the more energy the optic can handle. For pulse durations between 1 and 100 ns a scaling law<sup>[1]</sup> can be used to extrapolate the LIDT at a different pulse duration (y ns).

$$LIDT_{y\ ns} = LIDT_{x\ ns} \left[ \frac{y_{ns}}{x_{ns}} \right]^{0.35}$$

[1] Rainer F, Atherton LJ, Campbell JH, DeMarco FP, Kozlowski MR, Morgan AJ, Staggs MC (1992) *Four-harmonic database of laser-damage testing*. In: Bennet HE, Chase LL, Guenther AH, Newman BE, Soileau MJ (eds) *Laser-Induced Damage to Optical Materials*: 1991. SPIE 1624: 116–127.


# What can influence the LIDT of a component?

## ■ Optical component

- **Substrate:** Polishing residue, sub-surface damage, refractive index, optical quality (scratch/dig, etc.)
- **Surface preparation:** Adsorption of impurities from the environment,...
- **Material absorption:** Can cause changes in the microstructure, melting, delamination, cracks,...
- **Defects in the material:** Such as local under stoichiometry, cracks, particles, ...


## ■ Environmental factors

- **Temperature:** Stress in the film
- **Gas environment:** Chemical or physical reactions
- **Relative humidity:** Condensation

- 
- LIDT only meaningful for applications in which the environmental conditions are similar to the test conditions
  - Maximum energy density with which an optical component can safely be irradiated:
    - State of equilibrium between annealing of and new generation of defects
    - Defect concentration low enough to avoid catastrophic self-focusing
  - For lifetime critical applications, LIDT tests should be performed under conditions close to operating conditions

# Different measurement strategies



- Measurement according to ISO 21254 Standard
- Single-Shot Test (1-on-1)
  - At least 10 sites are irradiated with a predefined energy density (1 pulse per site)
  - Then the next 10 sites are irradiated with a higher energy density (1 pulse per site)
  - Continue the procedure with increasing energy density until all 10 sites are damaged
  - Microscopic inspection to verify the result
  - Results shown in a *damage probability curve*: damage probability vs. the energy density with a linear regression fit



The 0%-LIDT value is the energy density at which the linear fit has a 0% damage probability

# Different measurement strategies


- Measurement according to ISO 21254 Standard
- Multishot Test (S-on-1)
  - At least 10 sites are irradiated with S number of laser pulses of a predefined energy density
  - Determination of the probability of destruction as in the 1-on-1 measurement procedure
  - Repetition of the procedure at different predefined energy densities for S laser pulses
  - Results shown in a *damage probability curve* and for different pulse classes shown in a *Characteristic damage curve*
  - *Characteristic damage curve* converges to a finite energy density with increasing number of pulses
    - Convergence behaviour contains information about laser-induced aging mechanisms





# Different measurement strategies

- Measurement according to ISO 21254 Standard
- LIDT Certification
  - A number of sites on the component to be certified (usually only one sample site) are irradiated with the energy density to be certified
  - Tests are useful in the case you want to test expensive and unique optical parts
  - If no damage occurs, the optic can continue to be used






# Different measurement strategies

## ■ R-on-1 Ramp Test


- Several sites are irradiated with R pulses at steadily increasing energy density
- Irradiation of the next site as soon as destruction occurs or the number of pulses R is reached
- Representation as in S-on-1, but no linear regression possible
  - Indicate the LIDT as the largest energy density with 0% probability of destruction
- Useful with small surfaces (such as optical fibers or crystals)
- Method shows laser conditioning effect (LIDT increases with time)

→ Difficult interpretation



Above:



Matrix of LIDT measurement sites  
used in a ramp-test on a 3.6 mm x  
3.6 mm laser crystal



# Different measurement strategies

## ■ Raster Scan Test

- Individual laser pulses follow a serpentine raster pattern
- The irradiated sites overlap as they are separated by the 90% point of the Gaussian peak for a chosen focused spot diameter
- A predefined area of the component is scanned and damage observed via scattered light or microscopic inspection before and after irradiation
- Each site is exposed to a selected number of pulses at a selected energy density
- If all sites survive, the laser fluence is increased by a predetermined amount and the raster scan is run again on a new area of the component until damage is observed



Above:  
*Example of overlapping sites used during a raster scan measurement*

# Contact Details

*RhySearch*

Werdenbergstrasse 4

CH-9471

Buchs SG

[www.rhysearch.ch](http://www.rhysearch.ch)

*Daniel Schachtler*

*Scientific co-worker*

T +41 81 755 49 57

[daniel.schachtler@rhysearch.ch](mailto:daniel.schachtler@rhysearch.ch)

*Dr. Roelene Botha*

*Division manager: Optical Coatings*

T +41 81 755 49 66

[roelene.botha@rhysearch.ch](mailto:roelene.botha@rhysearch.ch)

***Join us at the Symposium on Optical Coatings for Laser Applications in Buchs on 8<sup>th</sup> April 2020!***

[www.rhysearch.ch/ocla](http://www.rhysearch.ch/ocla)